

## Receptor radio extern



### Program the hand-held remote control manually

- Press the learn button (**B**) to program a hand-held remote control. Press the learn button (**B**) several times to select the desired channels.
1. Press the learn button (**B**).
    - 1x for channel 1 (LED D.1 lights up)
    - 2x for channel 2 (LED D.2 lights up)
  2. Press the desired hand-held transmitter button within 10 seconds.
    - The LED goes out, programming process completed.

\*Chanel 1 OPEN-STOP-CLOSE-STOP-OPEN-...  
Chanel 2 DESCHIDERE PARTIALA

